

## TV Compatibility check with different Freecom & Verbatim Products

TV Model	Product	Recognition & Playback					Record Function			
		HDD Recognition	On/Off TV with device	Play			Record function supported by TV	Formatting	Record	Record + Playback
				Movies	Pictures	Music				
Blaupunkt W23/1731	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Grundig 32 VLE 6120 BF	Freecom Mobile Drive Classic 3.0	OK	OK	OK	OK	OK	No	-	-	-
Grundig 32 VLE 6120 BF	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Grundig 32 VLE 6120 BF	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Grundig 32 VLE 6120 BF	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Grundig 40 VLE 6120 BF	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Grundig 46 VLE 8160 SL	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Grundig 46 VLE 8160 SL	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Grundig 46 VLE 8160 SL	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Grundig 46 VLE 8160 SL	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
LG 42 LV 470S	Freecom Mobile Drive Classic 3.0	OK	OK	OK	OK	OK	No	-	-	-
LG 42 LV 470S	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
LG 42 LV 470S	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
LG 42 LV 470S	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
LG 42LK 430	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
LG 42LK 430	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
LG 42LK 430	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
LG 42LW 5590	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
LG 42LW 5590	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
LG 47 LV 470S	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
LG 47 LV 470S	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-
LG 47 LV 470S	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
LG 47 LW 5400	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
LG 47 LW 5400	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
LG 47 LW 5400	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
LG 47 LW 5400	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-
LG 47 LW 5400	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
LG 55LW 5795	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
LG 55LW 5795	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
LG 60 PV 250	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
LG 60 PV 250	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
OK OLE 220-B DVD D4	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
OK OLE 220-B DVD D4	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-
OK OLE 220-B DVD D4	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Orion TV 26LB	Freecom Mobile Drive Mg USB 3.0	OK	OK	not recognized	not recognized	not recognized	No	-	-	-
Orion TV 26LB	Verbatim Store n Go 3.0	OK	OK	not recognized	not recognized	not recognized	No	-	-	-
Orion TV 26LB	Verbatim Traveller	OK	OK	not recognized	not recognized	not recognized	No	-	-	-
Panasonic TX-L 32 EW 30	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-L 32 EW 30	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-L 32 EW 30	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-L 42 EW 30	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-L32 EW30 Silber	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-L32 EW30 Silber	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 42 GW30	Freecom Mobile Drive Classic 3.0	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 42 GW30	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 42 UT30E	Freecom Hard Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 42 UT30E	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 42 UT30E	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 42 UT30E	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 42 UT30E	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 466W 30	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-
Panasonic TX-P 466W 30	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
PEAQ PTV 32100 B	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
PEAQ PTV 32100 B	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
PEAQ PTV 32100 B	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-
PEAQ PTV 32100 B	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Philips 22 PFL 3606H	Freecom Hard Drive Sq	OK	OK	n.a.	OK	OK	No	-	-	-
Philips 22 PFL 3606H	Freecom Mobile Drive Mg USB 3.0	OK	OK	n.a.	OK	OK	No	-	-	-
Philips 22 PFL 3606H	Freecom Mobile Drive Sq	OK	OK	n.a.	OK	OK	No	-	-	-
Philips 22 PFL 3606H	Freecom Mobile Drive XXS 3.0	OK	OK	n.a.	OK	OK	No	-	-	-
Philips 22 PFL 3606H	Verbatim Executive Portable HD	OK	OK	n.a.	OK	OK	No	-	-	-
Philips 32 PFL 7606 K	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 32 PFL 7606 K	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Philips 32 PFL 7606 K	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 32 PFL 7606 K	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Philips 32 PFL 9606 K	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 32 PFL 9606 K	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Philips 32 PFL 9606 K	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Philips 40 PFL 9606 K/O2	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 40 PFL 9606 K/O2	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Philips 42 PFL 7656 K	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Philips 42 PFL 7656 K	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 42 PFL 7656 K	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 42 PFL 7656 K	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Philips 47 PFL 7456 K	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 47 PFL 7456 K	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Philips 47 PFL 7456 K	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 47 PFL 7456 K	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Philips 50 PFL 7956 K	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 50 PFL 7956 K	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 50 PFL 7956 K	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Philips 52 PFL 9606 K	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Philips 52 PFL 9606 K	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 52 PFL 9606 K	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Philips 52 PFL 9606 K	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Samsung PS-51 D 490 A1WXZG	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Samsung PS-51 D 490 A1WXZG	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 40 D 5700 RSXZG	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 40 D 5700 RSXZG	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 40 D 5700 RSXZG	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 46 C 6530	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 46 D 6200 TSXZG	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 46 D 6200 TSXZG	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 46 D 6200 TSXZG	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 46 D 6200 TSXZG	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Samsung UE 46 D 8090	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-
SEG Ancona 55	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
SEG Ancona 55	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-

SEG Ancona 55	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Sharp LC 32 LE510E	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sharp LC 32 LE510E	Verbatim Traveller	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 32 EX 720 BAEP	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 37 EX 525 BAEP	Freecom Hard Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Sony KDL 37 EX 525 BAEP	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Sony KDL 37 EX 525 BAEP	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Sony KDL 37 EX 525 BAEP	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Sony KDL 40 EX 525 BAEP	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 40 EX 525 BAEP	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Sony KDL 40 EX 525 BAEP	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 40 HX 725 BAEP	Freecom Mobile Drive Classic 3.0	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 40 HX 725 BAEP	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 40 HX 725 BAEP	Verbatim Traveller	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 46 EX 725 BAEP	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 46 EX 725 BAEP	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Sony KDL 46 EX 725 BAEP	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	No	-	-	-
Sony KDL 46 EX 725 BAEP	Verbatim Traveller	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 46 HX 725 BAEP	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 46 HX 725 BAEP	Verbatim Store n Go 3.0	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 46 HX 725 BAEP	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 46 HX 725 BAEP	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 55 HX 825 SUTI.YD+SU-B551S	Freecom Mobile Drive Classic 3.0	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 55 HX 825 SUTI.YD+SU-B551S	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Sony KDL 55 HX 825 SUTI.YD+SU-B551S	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Toshiba 37 BV701	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 37 BV701	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 37 BV701	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 40 TL 838 G	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 40 TL 838 G	Freecom Mobile Drive XXS 2.0	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 40 TL 838 G	Freecom Mobile Drive XXS 3.0	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 40 TL 838 G	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 42 VL 863 G	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 42 VL 863 G	Verbatim Executive Portable HD	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 46 UL 875G	Freecom Mobile Drive Sq	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 46 UL 875G	Verbatim Traveller	OK	OK	OK	OK	OK	No	-	-	-
Toshiba 46 WL863G	Freecom Mobile Drive Mg USB 3.0	OK	OK	OK	OK	OK	Yes	OK	OK	OK
Toshiba 46 WL863G	Verbatim Traveller	OK	OK	OK	OK	OK	Yes	OK	OK	OK